



Flexible Repair Pipes



Klarius N°	A(ID) mm	B mm	C mm	Klarius N°	A(ID) mm	B mm	C mm
FRP1J	38.5	152	280	FRP12L	48.5	251	390
FRP2H	38.5	203	330	FRP13K	51.5	152	290
FRP3G	38.5	262	400	FRP14J	51.5	203	340
FRP4E	42.5	152	280	FRP15H	51.5	251	390
FRP5D	42.5	203	330	FRP16G	54.5	152	290
FRP6C	42.5	262	400	FRP17E	54.5	203	330
FRP7B	45.5	152	280	FRP18D	54.5	251	390
FRP8A	45.5	203	340	FRP19C	57.5	152	290
FRP9X	45.5	262	400	FRP20B	57.5	243	400
FRP10P	48.5	152	290	FRP21A	60.5	152	290
FRP11M	48.5	203	340	FRP22X	60.5	243	390

Connection Pipes

Standard (90 mm length)



Klarius N°	A (ID) mm	Klarius N°	A (ID) mm
SLV1AE	38.5	SLV7AX	52.5
SLV2AH	40.5	SLV8AB	54.5
SLV3AK	42.5	SLV9AD	55.5
SLV4AM	45.5	SLV10AG	57.5
SLV5AQ	48.5	SLV11AJ	58.5
SLV6AV	50.5	SLV12AL	60.5

Deluxe



Klarius N°	A (ID) mm	A (OD) mm	Length mm	Klarius N°	A (ID) mm	A (OD) mm	Length mm
430462	43.0	46.7	80	430471	50.5	54.5	110
430463	43.0	46.7	90	430472	50.5	54.5	125
430464	43.0	46.7	125	430473	56.0	60.5	90
430465	45.0	49.5	80	430474	56.0	60.5	95
430466	45.0	49.5	90	430475	56.0	60.5	125
430467	46.0	50.5	125	430476	60.5	64.5	80
430468	50.5	54.5	80	430477	60.5	64.5	90
430469	50.5	54.5	90	430478	60.5	64.5	125
430470	50.5	54.5	95	430479	60.5	64.5	130

Emergency Repair Pipe

As used by leading motoring organisations.

Cut broken pipe & insert inside existing pipe. Tighten the bolt to expand & seal the unit. (A)

Can also be used when the pipe shears at the silencer (B).

Length approx 120mm



Klarius N°	Expansion mm
430449	28-32
430450	31-36
430451	35-41
430452	40-46
430453	45-53
430458	55-65

